

PHILLOCRAFT

INDIVIDUAL WORK SHOP


PHILLOCRAFT "INDIVIDUAL WORKSHOP TABLE" ASSEMBLY INSTRUCTIONS

- 1) ATTACH BOTTOM BRACE (#11) TO POST (#2) USING 5/16 X 3/4 HEX HEAD BOLTS, AND NUTS.
- 2) ASSEMBLE END CAPS (#4) TO POST (#2) USING 5/16 X 3/4 HEX HEAD BOLTS, AND NUTS.
- 3) CONNECT ADJUSTABLE LEG EXTENSION (#1) TO POST AT LOWER SET OF HOLES USING 1/2 X 7/8 HEX HEAD BOLTS, WASHER, AND NUTS.
- 4) CONNECT ANGLE CORNER BRACE (#8) L.H. AND (#8) R.H. USING 5/16 X 3/4 HEX HEAD BOLTS & NUTS.
- 5) CONNECT DIAGONAL CORNER BRACE (#6) TO POST AT UPPER SET OF HOLES USING 5/16 X 3/4 HEX HEAD BOLTS AND NUTS.
- 6) ATTACH TABLE TOP USING ROUND HEAD SHEET METAL SCREWS.

must drill 1/8" x 1/2"
deep pilot hole

TABLE ASSEMBLY INSTRUCTIONS

ITEM NO	DESCRIPTION	QTY.
1	ADJUSTABLE LEG EXTENSIONS	4
2	POST	4
4	END CAP	4
6	DIAGONAL CORNER BRACE	4
8	ANGLE CORNER BRACE LEFT HAND	2
8	ANGLE CORNER BRACE RIGHT HAND	2
11	BOTTOM BRACE	2
HARDWARE		
	ROUND HEAD SHEET METAL SCREW	12-24
	1/2 X 7/8 HEXHEAD BOLT, surr. flange nut, washer	4
	5/16 X 3/4 HEX HEAD, surrated flange nut	40



1029 INDIVIDUAL WORKSHOP TR ILLUSTRATION

6.4-2010

2007/04 → 2019/04